



**NOTE:**

1. FOR NON-HDPE PIPES, SILICONE TAPE SHOULD BE USED TO CREATE A SEAL BETWEEN THE BOOT AND THE PIPE IN LIEU OF A WELD

**GEOMEMBRANE/PIPE BOOT DETAIL**

NOT TO SCALE

STANDARD  
DETAIL

CITY OF BRISBANE  
DEPARTMENT OF PUBLIC WORKS

DATE: 07/01/21

LANDFILL GEOMEMBRANE  
PIPE BOOT DETAIL

LF - 6